


Key presses don't beep	Condition: Controller will not respond to button key press. Pressing keys will not cause a beep or change the display. Note: You may need to look up flow chart of any message stuck on the display or see Appendix 4 in your owners manual.	8.3e
		KM kilns
		Keyno.vsd



**Note**

5/28/2003

A stuck key can also cause the display to "hang" in a blank condition.