

KS kiln won't start

Condition:
Kiln Sitter kiln will not stay on or will not get warm.

8.6a

KS kilns

Ksnostar.vsd

